



Management Recommendations for Construction and Development Projects Affecting Missouri Karst Habitat

Purpose and Use

The information in this document is to be used to help avoid and minimize species impacts due to construction practices. It is not intended as a guide to manage habitat for a given species. Please contact the Department of Conservation if habitat management information is needed. Because every project and location differ, following the recommendations in this document does not guarantee impacts will not occur to the species and additional information may be required in certain instances. Following the recommendations in this document does not complete Endangered Species Act consultation that may be necessary for species listed under the federal Endangered Species Act; please contact the U.S. Fish and Wildlife Service for more information.

Introduction

Karst features range from sinkholes, vertical shafts, losing streams and springs, to complex underground drainage systems and caves. These features are the result of the dissolving action of water on carbonate bedrock. Underground drainage systems can be extensive; as a result, specific karst features can be impacted by disturbances occurring miles from the affected area. Associated with karst features are unique plants and animals that have at least part, if not all, of their life cycle dependent upon these unique systems. Even slight alterations or disturbances can have significant impacts upon these plants and animals. It is of utmost importance that construction projects in known karst topography be extremely sensitive to potential impacts and that all possible precautions are taken to prevent or reduce those impacts.

Karst Identification

It is often difficult to clearly delineate the type and extent of karst features in an area due to the complex and varied processes involved in their formation. However, it is important to correctly identify and delineate karst features so that construction in or near these areas is managed properly for the resident species (e.g., bat hibernaculum or bat maternity cave).

- Initial investigation should include the use of state, federal, and private geotechnical data. Observation by a geotechnical consultant should be considered if existing data indicate the presence of karst features in the vicinity. Initial geological investigation of the immediate and surrounding area of the proposed project site should be conducted to determine the presence and type of karst features.
- The identification and delineation of karst features should include the following: location, distribution,

and dimensions of rock cavities; location, distribution, and dimensions of soil voids; depth and configuration of the rock surface; variation in the physical characteristics of the subsurface soils and rock; groundwater quality and flow patterns.

Access/Staging Area Recommendations

Staging areas are short- or long-term sites within a construction or development area where most equipment and materials are stored. These areas are frequently accessed increasing the potential for runoff and erosion from these areas.

- Erosion and sediment controls should be installed and maintained to prevent discharge from the site.
- Staging areas for crew, equipment, and materials should be established well away from karst features such as caves, sinkholes, and springs, and highly erodible soils when practical.
- Stationary fuel and oil storage containers should remain within a staging area or another confined area to avoid accidental introduction into groundwater.
- Excess concrete and wash water from trucks and concrete mixing equipment should be disposed of well away from karst features, streams, and wetlands.
- If temporary roadways must be built, ensure that roadways are of low gradient with sufficient roadbed and storm water runoff drains and outlets.
- Appropriate containment basins, silt fences, filter strips, etc. should be included for retention of storm water runoff as a means for reducing sedimentation introduction into karst features and groundwater.

Buffer Zone Recommendations

The buffer zone is the vegetated area immediately surrounding the karst feature, which helps slow runoff and filter out pollutants that might enter karst systems. A vegetated buffer zone of at least 100-feet should be maintained on all sides around caves, sinkholes, and springs.

- Buffer zones located down slope of construction areas should be physically screened with sediment controls, such as silt fences or filter strips. Sediment controls should be monitored after rain and maintained for the duration of the project.
- General application of pesticides, herbicides, or fertilizers within the buffer zone should be avoided to avoid contamination due to over-spraying or runoff. Fertilizer use or spot application of pesticides and herbicides is acceptable if appropriate non-restricted chemicals are used.
- All buffer zones disturbed by the project should be revegetated immediately following or concurrent with project implementation. Native trees, shrubs, and

grasses should be planted to ensure long-term stability in areas where the soil erosion threat is not critical. Annual non-native grasses such as rye or wheat may be planted in conjunction with native species to provide short-term erosion control. Areas prone to immediate soil loss (e.g., steep slopes) may be planted with non-native mixtures to assure rapid establishment and erosion control.

- Post-construction evaluation of vegetation establishment should be conducted at one-month intervals for at least three months after completion of the project. Any recommended sediment controls should be inspected at these times. If determined beneficial to soil stability and not adversely impacting site function and/or aesthetics, recommended sediment controls should remain permanent.

Karst Area Recommendations

Karst areas provide habitat for a diversity of highly specialized and sensitive vertebrate and invertebrate animals. These areas also provide an important filtration system for the underground water humans use and drink. For this reason, it is important to avoid rerouting waterways and drainage patterns in karst areas.

- All construction debris, refuse, discarded containers, and any other waste materials should be stored away from karst areas and properly disposed of upon completion. Take care to contain this material to prevent its accidental introduction into caves, sinkholes, or springs as a result of cleanup activities, runoff, flooding, wind, or other natural forces.
- Sedimentation and erosion controls appropriate to soil type, water flows, exposure, and other site-specific factors should be implemented during all phases of construction and should be monitored periodically. Clean, repair, and replace controls as necessary.
- Final revegetation of disturbed areas should use native plant species. Grasses, such as rye or wheat, may be used with non-native mixtures initially to maintain soil stability until establishment of native vegetation can be completed. A monitoring program should be included in the project proposal to ensure successful revegetation efforts.
- All temporary erosion and sediment controls should be removed (unless removal would cause further disturbance) and disposed of within 30 days after final site stabilization is achieved or after temporary practices are no longer needed.

General Recommendations

If your project involves the use of Federal Highway Administration transportation funds, these recommendations may not fulfill all contract requirements. Please contact the Missouri Department of Transportation at 573-526-4778 or the [Missouri Department of Transportation Environmental Studies webpage](#) for additional information on recommendations.

Information Contacts

For further information regarding regulations for development in rivers and streams, contact:

For species information:

[Missouri Department of Conservation](#)

Science Branch
P.O. Box 180
2901 W. Truman Blvd
Jefferson City, MO 65102-0180
Telephone: 573-751-4115

For species information and Endangered Species Act Coordination:

[U.S. Fish and Wildlife Service](#)

Ecological Services
101 Park Deville Drive, Suite A
Columbia, MO 65203-0007
Telephone: 573-234-2132

For Clean Water Act Coordination:

[Missouri Department of Natural Resources](#)

Water Protection Program
P.O. Box 176
Jefferson City, MO 65102-0176
Telephone: 573-751-1300, 800-361-4827

[U.S. Army Corps of Engineers](#)

Regulatory Branch
700 Federal Building
Kansas City, MO 64106-2896
Telephone: 816-983-3990

[U.S. Environmental Protection Agency](#)

Water, Wetlands, and Pesticides Division
901 North 5th Street
Kansas City, KS 66101
Telephone: 913-551-7307

Disclaimer

These Best Management Practices were prepared by the Missouri Department of Conservation with assistance from state and federal agencies, contractors, and others to provide guidance to those who wish to voluntarily act to protect wildlife and habitat. Compliance with these Best Management Practices is not required by the Missouri wildlife and forestry law nor by any regulation of the Missouri Conservation Commission. Federal laws such as the Clean Water Act and the Endangered Species Act, and state or Local laws need to be considered for construction and development projects and require permits and/or consultation with the appropriate agency. Following the recommendations provided in this document will help reduce and avoid project impacts to the species, but impacts may still occur. Please contact the appropriate agency for further coordination and to complete compliance requirements.